
# HESSTAR


Instruction manual



WITH REMOTE CONTROL


16"STAND FAN

HF-816RS




### **Assembly diagram**


- (1 Loosen the screw from the tube and connect with the main body, then fasten the screw.
- (2) Assemble the main body into the aluminum tube then place into the small base.
- (3) Fasten the tube to the big base by the lock nut.
  - \* This product's warranty is void if used commercially.



- Place the well assembled fan on a flat surface before plugging into the socket.
  - Soft touch only is need to adjust the grill to the desirde fan angle.




#### \* Control panel function



#### Use Function Key to Control


- 1 Speed key-This key starts to turn on the fan. Press repeatedly for speed low (1), medium(2), high(3).
- 2. Timer key-Press repeatedly from 0.5 hour to 7.5 hours
- 3 Swing key Press repeatedly to swing Left & Right(1), Up & Down(2), figure"8"(3) and off(4) 4. Off key- Turn off the fan.


#### Remote controller function





## Oscillation

- 1.ONCE:LEFT-RIGHT OSCILLATION
- 2.TWICE'UP-DOWN OSCILLATON
- 3 THIRD: "8" OSCILLATION
- 4. FOURTH'STOP OSCILLATION











MODEL	HF-816RS
RATED VOLT	230-240V~ /50Hz
RATED POWER	55W
COLOR	BLACK


Never insert fingers into the guard when the fan is running.




Please keep a certain distance between the children and the fan.



Do not use the fan near water or fire otherwise it may cause electrical hazard.




Don't use the fan too near window because the curtain may be sucked into the fan which will lead to electrical hazard



Don't make the fan blowing straightly towardthe acid, oil and other chemical substances.




Be sure the fan is on a stable surface when operating to avoid overturning Before using the fan.



Please check whether the voltage used is in line with the voltage on the label of the fan or not.



Turn off the power before pulling the plug out.



- 1) Th s appl ance s not ntended for use by persons (including ch ldren) w th reduced physical Sensory or menta capabil t es, or lack of experience and knowledge, un ess they have been given supervision or nstruct on concerning use of the app iance by a person responsib e for the r safety
- Children should be supervised to ensure that they do not p ay with the appliance.
- 3) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or s milarly qualified persons in order to avoid a hazard