

HESSTAR

JUICER

Model : HJ-P80




INSTRUCTION MANUAL

Please read all instructions before use of this product.

Parts Name

- | | |
|-----------------------|---------------------------|
| ① Pusher | ⑥ Stainless Steel Housing |
| ② Top Cover | ⑦ Safety Lock |
| ③ Filter | ⑧ Switch |
| ④ Container Top Cover | ⑨ Juice Jug |
| ⑤ Pulp Collector | |



With your Centrifugal Juicer you can enjoy the delicious, natural tastes of the freshest juice from your own choice of fruit and vegetables. And it's easy to use. So enjoy a healthier lifestyle with this Juicer.

Important and safety

When using electrical appliances, basic safety precautions should always be followed.

including the following.

- 1 Read all instructions before use.
2. Do not use the juicer if the filter is damaged.
3. DO NOT operate the juicer without the pulp collector fitted.
4. TO prevent against risk of electrical shock ,do not immerse the electric cord ,plug or motor base in water or other liquid.
5. Switch off and unplug:
 - 1 Before fitting or removing parts
 - 2) Before cleaning.
 - 3) After use.
6. Never use a damaged juicer or cord/plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair ,electrical or mechanical adjustment.
- 7 Only use the pusher supplied. Close supervision is necessary when any appliance is used by or near children.
8. Avoid contact with moving parts.

Never put your fingers in the feed tube. Unplug before unblocking the feed tube.

9. Before removing the lid ,switch off and wait for the filter to stop.
10. Don't let children or infirm people use the juicer without supervision.
11. Never let the cord touch hot surfaces or hang down where a child could grab it.
12. Don't touch moving parts.
13. Never leave the juicer on unattended.
14. This juicer is for domestic use only.
15. Don't let children play with the machine.
16. To disconnect juicer wait until the motor stops before removing plug from electrical outlet.
- 17 Other than cleaning, no additional maintenance or servicing of this appliance is

required. Repairs, when necessary must be performed at an authorized Electrical service agent

18. Always unplug after use.

Before plugging in

1. Make sure your electricity supply is the same as the one shown on the underside of your juicer.
2. This juicer complies with European Economic Community Directive

Before using for the first time

1. Remove all packaging.
2. Wash the parts see 'Cleaning

Using your juicer

Preparing food

1. Remove stones (plums, peaches, cherries etc).
2. Remove tough skins (melons, pineapples, cucumbers, potatoes etc).
Soft-skinned and other foods just need washing (apples, pears, carrots, radishes, lettuce, cabbage, parsley, spinach, grapes, strawberries, celery etc).
3. Citrus Fruit- Peel and remove the white pith, otherwise the juice may taste bitter.

Assembly and use

1. Container top cover' ④ and pulp collector ⑤
2. Fit the filter' ③ inside the filter holder and push down- ensuring the filter is in the correct position.

3. Fit the lid. Lock the lid by lifting the safety locker to the lock position on the lid.

Your juicer will not work if the lid is unlocked.

Do not operate the juicer without the pulp collector fitted.

- 1 Put the juice jug under the outlet .And take off the lid with foam separator.
- 2 Switch on and feed the food item down with the pusher-ensuring the groove in the pusher aligns with the notch on the inside for the feed tube. Use low speed for soft food such as citrus and strawberries. With hard foods use the high speed.
- 3 Do not exert too much pressure on the pusher if the fruit or vegetables are too big, as this could affect the quality of the end result and it could even cause the juicer to come to a halt. Please ensure that you cut up larger fruits or vegetables into smaller size chunks that will fit easily into the large feed chute. When loading the cut pieces press gently down towards the rotating filter by means of the pusher.
- 4 Place the lid on the juice jug. The foam separator in the jug ensures that the juice is free from foam.
- 5 When juicing hard foods we recommend a maximum quantity of 1.5Kg with a maximum operation time of 2 minutes. Some very hard foods may make your juicer slow down or stop. If this happens switch off and unblock the filter.
- 6 Switch off and clear the pulp collector regularly during use.
- 7 The juicer is factory lubricated and requires no further lubrication.

To take your juicer apart

Reverse the assembly procedure to take the juicer apart.

Hints

- 1 Insert soft food slowly to get the most juice.
2. Vitamins disappear – the sooner you drink your juice, the more vitamins you'll get.
3. If you need to store the juice for a few hours put it in the fridge. It will keep better if you add a few drops of lemon juice.
4. Don't drink more than three 230mls (8 fl. oz.) glasses of juice a day unless you're

used to it.

5. Dilute juice for children with an equal amount of water.
6. Juice from dark green (broccoli, spinach etc or dark red (beetroot, red cabbage etc. vegetables is extremely strong so people with diabetes or low blood sugar should avoid drinking too much.

CLEANING

1. Before cleaning, unplug your juicer.
2. If the filter is too tight to remove, wait a few minutes until it loosens up.
3. Some foods e.g. carrot, will discolor the plastic. Rubbing with a cloth dipped in vegetable oil helps remove discoloring.

Filter

1. Use the brush supplied to clean.
2. Check the filter regularly for signs of damage. Do not use if the filter is damaged.

Other parts

Wash in hot soapy water, then dry all the parts .Don't clean parts in a dishwasher.

Noise Measurement

The noise level of this appliance is less than 78db